



**Specifications:**

<b>Model No</b> (X=1: →Clockwise) (X=2: ←Anticlockwise)	<b>Freq. Range</b> <b>MHz</b>	<b>Insertion</b> <b>Loss</b> <b>dB (max)</b>	<b>Isolation</b> <b>dB (min)</b>	<b>VSWR</b> <b>(max)</b>	<b>Power</b> <b>W</b>
WH1919X-X/850-855MHz	850-855	0.30	23.0	1.20	100
WH1919X-X/925-960MHz	925-960	0.35	23.0	1.20	100
WH1919X-X/1000-1200MHz	1000-1200	0.50	18.0	1.3	100
WH1919X-X/1030-1090MHz	1030-1090	0.35	20.0	1.20	100
WH1919X-X/1070-1210MHz	1070-1210	0.50	18.0	1.30	100
WH1919X-X/1100-1300MHz	1100-1300	0.50	18.0	1.30	100
WH1919X-X/1200-1400MHz	1200-1400	0.50	19.0	1.25	100
WH1919X-X/1250-1450MHz	1250-1450	0.40	20.0	1.25	100
WH1919X-X/1325-1375MHz	1325-1375	0.30	23.0	1.20	100
WH1919X-X/1450-1550MHz	1450-1550	0.30	23.0	1.20	100
WH1919X-X/1500-1700MHz	1500-1700	0.40	20.0	1.25	100
WH1919X-X/1550-1650MHz	1550-1650	0.30	23.0	1.20	100
WH1919X-X/1626-1660MHz	1626-1660	0.30	23.0	1.20	100
WH1919X-X/1700-1900MHz	1700-1900	0.40	20.0	1.25	100
WH1919X-X/1700-2000MHz	1700-2000	0.40	19.0	1.25	100
WH1919X-X/1710-1785MHz	1710-1785	0.30	23.0	1.20	100
WH1919X-X/1710-2170MHz	1710-2170	0.50	18.0	1.30	100
WH1919X-X/1800-2400MHz	1800-2400	0.60	18.0	1.30	100
WH1919X-X/1805-1880MHz	1805-1880	0.30	23.0	1.20	100
WH1919X-X/1805-2117MHz	1805-2117	0.40	20.0	1.25	100
WH1919X-X/1920-1990MHz	1920-1990	0.30	23.0	1.20	100
WH1919X-X/2000-2200MHz	2000-2200	0.40	20.0	1.20	100
WH1919X-X/2000-2400MHz	2000-2400	0.50	18.0	1.30	100
WH1919X-X/2100-2700MHz	2100-2700	0.50	18.0	1.35	100
WH1919X-X/2110-2170MHz	2110-2170	0.30	23.0	1.20	100
WH1919X-X/2135-2365MHz	2135-2365	0.40	20.0	1.25	100



<b>Model No</b> (X=1: →Clockwise) (X=2: ←Anticlockwise)	<b>Freq. Range</b> <b>MHz</b>	<b>Insertion</b> <b>Loss</b> <b>dB (max)</b>	<b>Isolation</b> <b>dB (min)</b>	<b>VSWR</b> <b>(max)</b>	<b>Power</b> <b>W</b>
WH1919X-X/2200-2300MHz	2200-2300	0.30	23.0	1.20	100
WH1919X-X/2200-2400MHz	2200-2400	0.40	20.0	1.20	100
WH1919X-X/2200-2500MHz	2200-2500	0.40	20.0	1.25	100
WH1919X-X/2300-2400MHz	2300-2400	0.30	23.0	1.20	100
WH1919X-X/2300-2500MHz	2300-2500	0.40	20.0	1.20	100
WH1919X-X/2300-2700MHz	2300-2700	0.40	20.0	1.20	100
WH1919X-X/2400-2600MHz	2400-2600	0.40	20.0	1.20	100
WH1919X-X/2496-2690MHz	2496-2690	0.40	20.0	1.20	100
WH1919X-X/2500-2700MHz	2500-2700	0.40	20.0	1.20	100
WH1919X-X/2600-2690MHz	2600-2690	0.30	23.0	1.20	100
WH1919X-X/2700-2900MHz	2700-2900	0.30	20.0	1.20	100
WH1919X-X/2700-3100MHz	2700-3100	0.40	20.0	1.25	100
WH1919X-X/2700-3500MHz	2700-3500	0.50	18.0	1.30	100
WH1919X-X/2900-3300MHz	2900-3300	0.40	20.0	1.20	100
WH1919X-X/2900-3500MHz	2900-3500	0.40	20.0	1.25	100
WH1919X-X/3100-3500MHz	3100-3500	0.40	20.0	1.25	100
WH1919X-X/3150-3250MHz	3150-3250	0.30	23.0	1.20	100
WH1919X-X/3300-3600MHz	3300-3600	0.30	20.0	1.20	100
WH1919X-X/3300-3800MHz	3300-3800	0.40	20.0	1.25	100
WH1919X-X/3400-3900MHz	3400-3900	0.40	20.0	1.25	100
WH1919X-X/3400-4200MHz	3400-4200	0.45	19.0	1.25	100
WH1919X-X/3400-4300MHz	3400-4300	0.50	18.0	1.30	100
WH1919X-X/3550-3700MHz	3550-3700	0.30	23.0	1.20	100
WH1919X-X/3600-3800MHz	3600-3800	0.30	23.0	1.20	100
WH1919X-X/3900-4200MHz	3900-4200	0.30	23.0	1.20	100
WH1919X-X/3900-4500MHz	3900-4500	0.40	20.0	1.25	100
WH1919X-X/4000-4500MHz	4000-4500	0.40	19.0	1.25	100
WH1919X-X/4200-4700MHz	4200-4700	0.40	20.0	1.25	100

Model No (X=1: →Clockwise) (X=2: ←Anticlockwise)	Freq. Range MHz	Insertion Loss dB (max)	Isolation dB (min)	VSWR (max)	Power W
WH1919X-X/4400-5000MHz	4400-5000	0.40	20.0	1.25	100

#### Instructions:

- 1, The circulator only provides through power, indicating that the transmission to the antenna and the antenna to the receiving are through power;
- 2, Only some common frequencies in the table, can be produced according to user requirements;
- 3, Embedded circulator, please use stainless steel or brass screws when installing;
- 4, If you do not find what you are looking for, please contact us!